City of Carlsbad



Engineering Standards

Volume 4
SWPPP Manual
CONSTRUCTION BMP'S

2022 Edition

CITY OF CARLSBAD ENGINEERING STANDARDS

TABLE OF CONTENTS

VOLUME 4

SWPPP MANUAL

REVISIONS/ADDENDUM									
CHAPTER/ PAGE/DWG.	ITEM	REVISION DATE							
All of Volume 4	I I								
Revised Cover Sheet (all), Table of Contents (all), Introduction (all), Chapter 2 text (all) Chapter 2 Appendix C (all), Chapter 3 text (all) and Chapter 3 Appendix B. Added Chapter 2 Appendix G	Changed all Section references to Chapter references. Minor revisions throughout Chapters 2 and 3 to correct typographical errors, correct certain document references and improve clarity. Update Storm water Standards Questionnaire on redevelopment projects. Revised list of exempted projects on page 10 of Chapter 3 and on Storm Water Compliance Exemption Form in Appendix B. Cover Sheet revised to read '2004 Version' with listed revision dates. Added Appendix G (Interim Hydromodification Criteria) to Chapter 2. Revised Chapter 2 Appendix C to specify Qualified SWMP Preparer.	6/04/2008							
Update Chapter 2	Update priority project type to include 1-acre projects	1/22/10							
Update Chapters 1 & 2	Replace entire chapters to implement new model SUSMP requirements as required by Order 2007-01	3/24/10							
Update Chapters 1 & 2	Replace entire chapters to incorporate hydromodification requirements as required by Order 2007-01	1/14/11							
All	Remove SUSMP added BMP Design Manual (see Volume 5), Update SWPPP Volume	2/16/16							
All Chapters	Various Revisions Throughout	4/29/2022							

SWPPP Standards and Requirements

Table of Contents

<u>Cr</u>	<u>napter</u>	Title	<u>Page</u>
1.	SWPP	P Standards Introduction	2
	4.4	De alamana d'Information	0
	1.1	Background Information	
	1.2	Applicable Regulations to Construction Projects	2
2.	SWPP	P Requirements and Approval Process	3
	2.1	SWPPP Tier Levels	
	2.2	Determination of SWPPP Tier Level	
	2.3	Qualified Persons to Prepare a Construction SWPPP	4
	2.4	Required Elements for Tier 3 SWPPP	4
	2.5	Required Elements for Tier 2 and Tier 1 Construction SWPPP	5
	2.6	Inspection Fee Commensurate to Construction Threat	5
3.	Const	ruction BMP Standards	6
	3.1	Background Information	6
	3.2	Minimum BMP Requirements	6
	3.3	Erosion and Sediment Control BMPs	7
	3.4	Erosion Control BMPs	8
	3.5	Sediment Control BMPs	9
	3.6	Wind Erosion Control BMPs	10
	3.7	Tracking Control BMPs	
	3.8	Non-Storm Water Management BMPs	
	3.9	Waste Management and Materials Pollution Control BMPs	
	3.10		
	3.11	<u> </u>	
4.	Storm	Water BMP Inspection and Maintenance	16
	4.1	General Information	
	4.2	Inspection of Construction Sites	16
	4.3	·	
	4.4	City Storm Water BMP Inspection Requirements	
	4.5	BMP Verification of Installation Required Prior to Occupancy	
<u>Li:</u>	st of Ta	<u>bles</u>	
Ta	able 1:	City Construction Permits Types Exempt from SWPPP Requirements	4
	able 2:	Erosion Control BMPs	
Ta	able 3:	Sediment Control BMPs	
	able 4:	Wind Erosion Control BMPs	10
	able 5:	Tracking Control BMPs	
	able 6:	Non-Storm Water Management BMPs	
Ta	able 7:	Waste Management and Materials Pollution Control BMPs	
Ta	able 8:	Inspection Frequency Based on Threat Prioritization	

1. SWPPP Standards Introduction

1.1 Background Information

The Construction Storm Water Pollution Prevention Plan (SWPPP) standards and requirements described herein were established to ensure construction compliance with the City of Carlsbad Storm Water Ordinance and the Municipal Permit, as issued by the San Diego Regional Water Quality Control Board (RWQCB) (see below for Municipal Permit reference details). This chapter must be used in conjunction with other chapters of this manual to ensure full compliance with both construction and post construction storm water requirements. This chapter addresses the need for temporary Best Management Practices (BMPs) during construction activities to minimize the mobilization of pollutants such as sediment and to minimize the exposure of storm water to pollutants.

1.2 Applicable Regulations to Construction Projects

All construction activities within the City are subject to the requirements of Carlsbad Municipal Code (CMC) 11.16, 15.12, 15.16 and 18.48, 2015 Jurisdictional Runoff Management Program (JURMP), and requirements of this manual.

The water quality protection measures and construction procedures described in this chapter of the manual are intended to ensure construction activity compliance with the following State and Regional water quality permits:

Municipal Permit - The San Diego California Regional Water Quality Control Board (SDRWQCB) San Diego Region Order No. R9-2013-0001, as amended by Order Nos. R9-2015-0001 and R9-2015-0100; National Pollutant Discharge Elimination System (NPDES) No. CAS0109266 and Waste Discharge Requirements for Discharges from the Municipal Separate Storm Sewer Systems (MS4s) Draining the Watersheds within San Diego Region and any amendment, revision, or re-issuance thereof; and,

Construction General Permit (CGP) - The NPDES General Permit for Storm Water Discharges Associated with Construction and Land Disturbance Activities, Order No. 2009-0009-DWQ amended by 2010-0014 and 2012-0006-DWQ NPDES No. CAS000002, adopted by the State Water Resources Control Board on July 17, 2012 and any amendment, revision, or re-issuance thereof.

To obtain a copy of the Municipal Permit and/or CGP, general information about the permits and fact sheets, visit RWQCB website at:

http://www.swrcb.ca.gov/rwqcb9/

2. SWPPP Requirements and Approval Process

2.1 SWPPP Tier Levels

Construction activities within the City that have the potential to negatively affect water quality must prepare a construction storm water pollution prevention plan (SWPPP). To ensure compliance with all the various State and Regional permitting regulations, the City has established a three-tiered system for the preparation of SWPPPs. The tiers range from Tier 1 representing the lowest threat to water quality to Tier 3 representing the highest threat to water quality (Refer to section 2.2 of this manual for Tier level determination). Some construction activities are exempt from SWPPP requirements (see Table 1, section 2.2).

Exempt - Construction activities that pose no threat to storm water quality are exempt from the preparation of a SWPPP; however, the construction activities must still comply with all construction BMPs required pursuant to Title 15 of the CMC and these standards.

Tier 1 SWPPP – Construction activities that impact less than one acre and pose a low threat to storm water quality must prepare a Tier 1 Construction SWPPP in conformance with City Standards.

Tier 2 SWPPP – Construction activities that impact less than one acre and that pose a moderate threat to storm water quality must prepare a Tier 2 Construction SWPPP in conformance with City Standards.

Tier 3 SWPPP - Construction activities covered under the CGP or those which pose a significant potential for storm water quality impairment must prepare a Tier 3 Construction SWPPP in conformance with the standards and requirements of the Construction General Permit and City Standards.

2.2 Determination of SWPPP Tier Level

City Form E-32 "Determination of Project's SWPPP Tier Level and Construction Threat Level", available on the City website, shall be used to determine the appropriate tier level of SWPPP for a proposed construction project. It provides threshold triggers or criteria for each of the three tier levels and provides list of exempt projects.

Form E-32 is also used to determine the appropriate construction threat level (high, medium, or low) to storm water. The project's construction threat to storm water quality relates to the frequency of storm water compliance inspections required under the Municipal Permit and is one of the factors used to determine the City Construction SWPPP inspection fee. The completed Form E-32 shall be submitted with applications for each construction permit submitted to the City including building permits, grading permits and right-of-way permits.

Exempt projects must comply with all storm water BMPs pursuant to Title 15 of the CMC and City Standards. If the City Engineer, which is hereby defined as the "City Engineer or designee" or Building Official finds that an otherwise exempt project could potentially pose a threat to storm water quality, the City Engineer or Building Official may require preparation and implementation of a SWPPP at a tier level commensurate with the storm water threat.

Table 1

City Construction Permit Types Exempt from SWPPP Requirements

Electrical Permit
Fire Additional Permit
Fire Alarm Permit
Mechanical Permit
Mobile Home Permit
Re-Roofing Permit

Roof Mounted Solar Array Patio Deck

Plumbing Permit Sign Permit

Spa – Factory Made Fire Sprinkler Permit

Cautionary Note - The Project Threat Assessment Worksheet represents the applicant's (project proponent) assessment of the threat posed by a proposed construction project. City staff has responsibility for making the final assessment regarding the need for and tier level of SWPPP required The City staff decision is made after submission of the plan review application. A staff determination that the construction plan review application is subject to the preparation of a SWPPP, or is subject to more stringent SWPPP requirement than initially assessed by the applicant (project proponent), will result in the return of the plan review application as incomplete.

If applicants are unsure about the meaning of any of the assessment criteria described in the worksheet or need help in determining how to respond to one or more of the assessment criteria, they are strongly encouraged to seek assistance from Development Services staff prior to preparation of the SWPPP and submission for construction plan review.

2.3 Qualified Persons to Prepare Construction SWPPP

Tier 3 SWPPPs shall be prepared in accordance with the requirements of the CGP. Section VII.B of CGP provides SWPPP Certification requirements. The discharger shall ensure that the Tier 3 SWPPP is written, amended, and certified by a Qualified SWPPP Developer (QSD).

Tier 2 SWPPPs shall be prepared in accordance with the requirements of this manual. Unless otherwise approved, all Tier 2 SWPPPs shall be written and amended by an appropriate certified professional.

No special qualification is required to prepare a Tier 1 SWPPP, however the City highly recommends that the SWPPP be prepared by a qualified erosion control professional.

2.4 Required Elements for Tier 3 SWPPP

A Tier 3 SWPPP must contain all of the elements required by the CGP. To aid in the preparation of a Tier 3 SWPPP, the preparer may utilize the SWPPP template included in the latest version of the "California Stormwater BMP Handbook Construction" prepared by the California Storm Water Quality Association (CASQA).

The use of the SWPPP template does not guarantee compliance with the CGP or these standards. Additionally, using the outline to generate a Tier 3 Construction SWPPP is not a substitute for knowledge of the permit requirement. The outline serves as a guidance document only. A site-specific Tier 3 Construction SWPPP must be combined with proper and timely installation, inspection, maintenance, and documentation of BMPs.

To avoid unnecessary SWPPP amendments through the RWQCB, do not upload the SWPPP to the Storm water Multi-Application and Report Tracking System (SMARTS) until reviewed and accepted by the City. After City review of the Tier 3 SWPPP and prior to signature of the grading plans and/or issuance of grading permit, the project proponent (owner/developer/applicant) must obtain coverage under the CGP by filing the required documentation through the RWQCB's SMARTS website.

Upon filing of the Notice of Intent (NOI), the project will be assigned a Waste Discharger's Identification (WDID) number from SMARTS. The WDID number must be added into the Tier 3 Construction SWPPP and affixed onto the respective construction plans.

The project is only considered covered by CGP upon receipt of a WDID number assigned and sent by the SMARTS system. In order to demonstrate compliance with CGP, the project proponent must present documentation of a valid WDID upon request. (See CGP II.A and B).

The QSD and Qualified SWPPP Practitioner (QSP) are responsible for ensuring full compliance with the CGP and for the implementation of all elements of the Tier 3 SWPPP including storm water and non-storm water visual observations, monitoring, sampling and analysis, preparation of annual compliance evaluation and elimination of all unauthorized discharges.

2.5 Required Elements for Tier 2 and Tier 1 Construction SWPPP

The project proponent shall utilize the City's Tier 1 or Tier 2 SWPPP templates and include all applicable elements provided in the template. The SWPPP templates are available on the City website.

Tier 1 and Tier 2 SWPPP templates include standard storm water prevention construction notes, a project information block, a Storm Water Compliance Statement, City approval block and a BMP Checklist Table. The BMP Checklist Table is intended to help the project proponent select appropriate BMPs best suited to the project. Additionally, the SWPPP shall include a site plan showing the proposed project site and depicting the areas of proposed construction and proposed locations of construction BMPs. The Tier 1 and Tier 2 SWPPP plans shall be submitted as additional sheets to the construction plan set.

The use of the template does not guarantee compliance with these standards. Additional BMPs may be required if the selected BMP(s) are shown to be ineffective or not relevant to a particular construction activity. Tier 1 and Tier 2 SWPPP must be combined with proper and timely installation of the BMPs, thorough and frequent inspections, maintenance, and documentation. The project proponent is responsible for ensuring that the selected BMPs are appropriately incorporated into the site design and if necessary, employ a qualified professional to ensure proper installation and maintenance of the BMPs. Consideration shall be given for the various phases of a project. A compliant site may require the redeployment of BMPs, the re-configuration of BMPs and/or the use of different types of BMPs to adapt to changes in site conditions through the various phases of construction.

2.6 Inspection Fee Commensurate to Construction Threat

The Municipal Permit requires the City provide inspection fees commensurate with a project's potential construction threat to storm water quality. A project's potential construction threat to storm water quality relates to the frequency of storm water compliance inspections and is one of the factors used to determine the SWPPP inspection fee. The potential construction threat level is determined using Form E-32 (see section 2.2). For more detailed information on storm water compliance inspections please refer to Chapter 3.4 of this manual.

3. Construction BMP Standards

3.1 Background Information

As construction activities occur, the City requires projects to plan for and implement temporary construction BMPs to mitigate the water quality impacts of land disturbance and non-storm water discharges related to construction activities. BMPs are the schedules of activities, prohibitions of practices, maintenance procedures and other management practices employed during construction activities to prevent or reduce pollution of the ocean, lagoons, lakes, streams and other sensitive water bodies and water courses. Construction BMPs also include the physical devices and structural construction control measures designed to prevent soil erosion from occurring or to contain sediment before it leaves the construction site. BMPs are also intended to protect the health, safety, and welfare of the public and to prevent damage to adjoining public and private property resulting from construction activities.

Pollution prevention practices and the minimum BMPs are required year-round. BMPs and other erosion control practices must be implemented as the most important "first line of defense". The City has adopted the CASQA 'Stormwater Best Management Practices Handbook: Construction', latest edition, as its preferred source for construction BMPs. All BMP reference numbers used in this manual correspond to the BMP Fact Sheets included in the CASQA construction handbook. With the approval of the City Engineer, or designee, the City may accept comparable BMPs from reputable alternative sources (e.g., Caltrans).

This manual is not intended as a comprehensive engineering or design manual on BMPs. The QSD or other qualified storm water professional must utilize their knowledge and experience with the tools and reference materials described in this manual to prepare an appropriate and adequate SWPPP.

The BMP categories described in the CASQA construction handbook also inform the checklist of BMPs to be included in the Construction SWPPP. The combination of BMPs included in the SWPPP must reflect the specific conditions at the proposed construction site. An effective SWPPP includes combination of BMPs that are designed to work together.

3.2 Minimum BMP Requirements

The City has established a set of minimum BMPs for all projects. Because all sites, regardless of priority, must be protected to prevent discharges, the minimum BMP requirements are the same for each priority. Each site must be protected by an effective combination of site and seasonally specific erosion and sediment controls, materials and waste management controls, and site management controls.

In addition, inactive sites must also be fully protected from erosion and discharges of sediment. A site is considered inactive if construction activities cease for a period of fourteen (14) days or more consecutive days. It is also the project proponent's responsibility, at both active and inactive sites, to implement a plan to address all potential discharges. The City requires the following minimum BMPs components for all construction sites:

- 1. Project Planning:
- 2. Good site management "Housekeeping", including waste management;
- 3. Non-storm water management;
- 4. Erosion control;
- 5. Sediment control;
- 6. Run-on and Run-off control.

If a particular BMPs is infeasible to implement, the project proponent shall install an equivalent or additional BMPs to achieve the intended performance. At any time of the year an inactive site must be fully protected from erosion and discharges of sediment. It is the project proponent's responsibility at both active and inactive sites to implement a plan to address all potential storm water and non-storm water discharges.

3.3 Erosion and Sediment Control BMPs

Erosion and sediment control BMPs are structural and non-structural practices intended to prevent soil erosion (erosion control) and to capture sediment displaced by storm water before it leaves the site (sediment control). Erosion and sediment control are the heart of any effective SWPPP. The SWPPP should rely on erosion control as the primary means of preventing storm water pollution. Sediment controls provide a necessary second line of defense to properly designed and installed erosion controls.

3.4 Erosion Control BMPs

Erosion control is any source control practice that protects the soil surface and prevents soil particles from being detached by rainfall, flowing water or wind. Erosion control is referred to as soil stabilization. Erosion control consists of preparing the soil surface and implementing one or more of the BMPs shown in Table 2.

All inactive soil-disturbed areas on the project site, and most active areas prior to the onset of rain, must be protected from erosion. Soil disturbed areas may include relatively flat areas as well as slopes. Typically, steep slopes and large exposed areas require the most robust erosion controls; flatter slopes and smaller areas still require protection, but less robust measures may be appropriate for these areas allowing resources to be directed to slopes and large exposed areas. Erosion control BMPs must be implemented at slopes and disturbed areas to protect them from concentrated flows.

Some erosion control BMPs can be used effectively to temporarily prevent erosion by concentrated flows.

These BMPs prevent erosion by intercepting, diverting, conveying and discharging concentrated flows in a manner that prevent soil detachment and transport. Temporary concentrated flow conveyance controls may be required to direct run-on around or through the project in a non-erodible fashion.

Table 2							
Erosion Control BMPs							
CASQA BMP#	BMP Name						
EC-1	Scheduling						
EC-2	Preservation of Existing Vegetation						
EC-3	Hydraulic Mulch						
EC-4	Hydroseeding						
EC-5	Soil Binders						
EC-6	Straw Mulch						
EC-7	Geotextiles & Mats						
EC-8	Wood Mulching						
EC-9	Earth Dikes and						
	Drainage Swales						
EC-10	Velocity Dissipation Devices						
EC-11	Slope Drains						
EC-12	Streambank Stabilization						
EC-14	Compost Blanket						
EC-15	Soil Preparation/Ro ughening						
EC-16	Non-vegetative stabilization						

3.5 Sediment Control BMPs

Sediment control is any practice that traps soil particles after they have been detached and moved by rain, flowing water, or wind. Sediment control measures are usually passive systems that rely on filtering or settling the particles out of the water or wind that is transporting them. Sediment control practices include the BMPs listed in Table 3.

Sediment control BMPs include those practices that intercept and slow or detain the flow of storm water to allow sediment to settle and be trapped. Sediment control practices can consist of installing linear sediment barriers (such as silt fence, sandbag barrier, and straw bale barrier); providing fiber rolls, gravel bag berms, or check dams to break up slope length or flow; or constructing a sediment trap or sediment basin. Linear sediment barriers are typically placed below the toe of exposed and erodible slopes, down-slope of exposed soil areas, around soil stockpiles, and at other appropriate locations along the site perimeter.

A few BMPs may control both sediment and erosion, for example, fiber rolls and sand bag barriers. The CASQA Construction Handbook classifies these BMPs as either erosion control (EC) or sediment control (SE) based on the BMPs most common and effective use. Sediment control BMPs are most effective when used in conjunction with erosion control BMPs. The combination of erosion control and sediment control is usually the most effective means to prevent sediment from leaving the project site and potentially entering storm drains or receiving waters. The City requires that the discharger implement an effective combination of erosion and sediment controls.

Table 3 Sediment Control BMPs							
CASQA BMP#	BMP Name						
SE-1	Silt Fence						
SE-2	Sediment Basin						
SE-3	Sediment Trap						
SE-4	Check Dams						
SE-5	Fiber Rolls						
SE-6	Gravel Bag Berm						
SE-7	Street Sweeping and Vacuuming						
SE-8	Sandbag Barrier						
SE-9	Straw Bale Barrier						
SE-10	Storm Drain Inlet Protection						
SE-11	Active Treatment Systems						
SE-12	Manufactured Linear Sediment Control (MLSC)						
SE-13	Compost Socks and Berms						
SE-14	Biofilter Bags						

Under limited circumstances, sediment control alone may be appropriate. For example, applying erosion control BMPs to an area where excavation, filling, compaction, or grading is currently under way may not be feasible when storms come unexpectedly. Use of sediment controls by establishing perimeter control on these areas may be appropriate and allowable provided the following conditions are met:

- Weather monitoring is under way.
- Inactive soil-disturbed areas have been protected with an effective combination of erosion and sediment controls.
- An adequate supply of sediment control materials is stored on-site and there are sufficient forces
 of labor and equipment available to implement sediment controls on the active area prior to the
 onset of rain.
- The SWPPP adequately describes the methods to protect active areas.

3.6 Wind Erosion Control BMPs

Wind erosion control consists of applying water or other dust palliatives to prevent or alleviate dust nuisance. Wind erosion control BMPs are shown in Table 4.

Other BMPs that are sometimes applied to disturbed soil areas in order to control wind erosion are BMPs EC-2 through EC-7 shown in Chapter 3.4 above Be advised that n

Table 4 Wind Erosion Control BMPs							
CASQA	BMP Name						
BMP#	DIVIF Name						
WE-1	Wind Erosion Control						

through EC-7, shown in Chapter 3.4 above. Be advised that many of the dust palliatives may contain compounds that have an unknown effect on storm water. A sampling and analysis protocol to test for storm water contamination from exposure to such compounds is required in the SWPPP.

3.7 Tracking Control BMPs

Tracking control consists of preventing or reducing the tracking of sediment off-site by vehicles leaving the construction area. Tracking control best management practices (BMPs) are shown in Table 5.

Attention to control of tracking sediment off site is highly recommended, as dirty streets and roads near a construction site create a nuisance to the public and generate constituent complaints to elected officials and regulators. These complaints often result in immediate inspections and regulatory actions.

Table 5 Tracking Control BMPs							
CASQA BMP Name							
TC-1	Stabilized Construction Entrance/Exit						
TC-2	Stabilized Construction Roadway						
TC-3	Entrance/Outlet Tire Wash						

3.8 Non-Storm Water Management BMPs

Carlsbad standards prohibit the discharge of materials other than storm water and authorized non-storm water discharges. It is recognized that certain non-storm water discharges may be necessary for the completion of construction projects. Such discharges include but are not limited to irrigation of vegetative erosion control measures, pipe flushing and testing, and street cleaning.

Non-storm water management BMPs are source control BMPs that prevent pollution by limiting or reducing potential pollutants at their source or eliminating off-site discharge. These practices involve day-to-day operations of the construction site and are usually under the control of the contractor. These BMPs are also referred to as "good housekeeping practices" which involve keeping a clean, orderly construction site.

Non-storm water management BMPs also include procedures and practices designed to minimize or eliminate the discharge of pollutants from vehicle and equipment cleaning, fueling, and maintenance operations to storm water drainage systems or to watercourses.

Table 6 lists standard non-storm water management BMPs. All these BMPs must be implemented depending on the conditions and applicability of deployment described as part of the BMP.

It is recommended that owners and contractors be vigilant regarding implementation of these BMPs, including making their implementation a condition of continued employment, and part of all prime and subcontract agreements. By doing so, the chance of inadvertent violation can be prevented, potentially saving thousands of dollars in fines and project delays. Also, if procedures are not properly implemented and/or if BMPs are compromised then the discharge is subject to sampling and analysis requirements contained in the CGP.

Table 6 Non-Storm Water Management BMPs							
CASQA BMP#	BMP Name						
NS-1	Water Conservation Practices						
NS-2	Dewatering Operations						
NS-3	Paving and Grinding Operations						
NS-4	Temporary Stream Crossing						
NS-5	Clear Water Diversion						
NS-6	Illicit Connection/Discharge						
NS-7	Potable Water/Irrigation						
NS-8	Vehicle and Equipment Cleaning						
NS-9	Vehicle and Equipment Fueling						
NS-10	Vehicle and Equipment Maintenance						
NS-11	Pile Driving Operations						
NS-12	Concrete Curing						
NS-13	Concrete Finishing						
NS-14	Material and Equipment Use						
NS-15	Demolition Adjacent to Water						
NS-16	Temporary Batch Plants						

3.9 Waste Management and Materials Pollution Control BMPs

Waste management and materials pollution control BMPs, like non-storm water management BMPs, are source control BMPs that prevent pollution by limiting or reducing potential pollutants at their source before they come in contact with storm water. These BMPs also involve day-to-day operations of the construction site, are under the control of the contractor, and are additional "good housekeeping practices" which involve keeping a clean, orderly construction site.

Waste management consists of implementing procedural and structural BMPs for handling, storing, and disposing of wastes generated by a construction project. The objective is to prevent the release of waste materials into storm water runoff or discharges through proper management of the following types of wastes:

- > Solid
- Sanitary
- Hazardous
- Equipment-related wastes

Materials pollution control (also called materials handling) consists of implementing procedural and structural BMPs in the handling, storing, and the use of construction materials. The BMPs are intended to prevent the release of pollutants during storm water and non-storm water discharges. The objective is to prevent or reduce the opportunity for contamination of storm water runoff from construction materials by covering and/or

Waste Management and Materials Pollution Control BMPs								
CASQA BMP#	BMP Name							
WM-1	Material Delivery and Storage							
WM-2	Material Use							
WM-3	Stockpile Management							
WM-4	Spill Prevention and Control							
WM-5	Solid Waste Management							
WM-6	Hazardous Waste Management							
WM-7	Contaminated Soil Management							
WM-8	Concrete Waste Management							
WM-9	Sanitary/ Septic Waste Management							
WM-10	Liquid Waste Management							

Table 7

providing secondary containment of storage areas, and by taking adequate precautions when handling materials. These controls must be implemented for all applicable activities, material usage, and site conditions.

Table 7 lists the waste management and materials pollution control BMPs. It is important to note that these BMPs should be implemented depending on the conditions/applicability of deployment described as part of the BMP.

3.10 General Site Management Requirements

BMPs must be site specific, seasonal, construction phase appropriate and <u>implemented year-round</u>. It is the City's goal to obtain construction site compliance with the following applicable BMP requirements:

- Construction sites must maintain emergency stockpiles of BMPs onsite throughout the year. The following BMP quantities are <u>in addition to</u> the amount of materials required to be installed according to the SWPPP:
 - a. Silt Fence 25%
 - b. Rock Bags 125%
 - c. Fiber Rolls 50%
 - d. Tracking Control 25%
 - e. Other BMPs Determined as needed.

- 2. BMPs must be stockpiled at various, accessible locations throughout the site for the duration of the project. Whenever there is a **40**% chance of a rain event within a 72-hour (three day) forecast, the contractor / person(s) who are in responsible charge of the project site must conduct a pre-event inspection to verify that BMPs are stockpiled and that the site is adequately protected. BMPs must be ready for deployment when there is a 50% chance of rain within a 48-hour forecast. Failure to comply may result in the issuance of a Stop Work Notice or other enforcement action.
- 3. Projects covered under the CGP designated as Risk Level 2 and 3 sites are required to have a professional erosion control company under contract and available to respond during emergency situations. It is highly recommended that all construction sites have a professional erosion control company available to respond during emergency situations.
- 4. All erosion and sediment control measures must be installed prior to performing demolition or ground disturbance activities such as clearing and grubbing or grading. Erosion and sediment control BMPs shall be maintained to ensure proper functionality throughout the duration of the project. If a BMP fails it must be repaired or replaced with a new BMP capable of meeting the function and performance requirements for the intended application.
- 5. Deployment of the appropriate erosion control BMPs shall commence as soon as slopes or disturbed areas are completed or if left inactive for 14 or more days.
- 6. Adequate BMPs to control offsite sediment tracking must be installed and maintained throughout the duration of the project.
- 7. All construction workers, including subcontractors, must be trained on the importance of storm water pollution prevention and BMP maintenance. Training shall occur prior to the commencement of construction activities when new employees join the project and then again for all workers between August 1 and October 1 of each year thereafter. Training records must be retained within the SWPPP and available upon request.
- 8. The contractor shall provide the City's inspector with the contact information (including name, phone number and email) of the QSP or erosion control professional responsible for verification of BMP compliance.
- 9. The QSP or erosion control professional must conduct a BMP compliance inspection prior to each forecasted event of 50% or greater, after each rain event and weekly between October 1 and May 1 of each year. The contractor must implement the corrective actions and recommendations from the QSP's pre-event inspection prior to the start of the rain event. Accordingly, the QSP and contractor are advised to conduct the pre-event inspection as soon as possible. The contractor is further advised to ensure adequate stockpiles of BMPs are stored onsite and available for a timely deployment in accordance with the QSP's recommendations.
- 10. The project proponent shall have an approved "weather triggered" action plan and be able to deploy BMPs to protect exposed portions of the site within 48 hours of a predicted rain event. A predicted storm event is defined as a 40% chance of rain within a 3-day National Weather Service forecast.
- 11. The maximum area that can be cleared, graded and left exposed at any given time shall be limited to the area (i.e. acreage) that the contractor can adequately protect prior to a predicted rain event. Due to the risk of a discharge, grading of large sites and sites situated on a slope are advised to be performed in phases. It may be necessary to deploy erosion and sediment control BMPs in areas that are not completed but are not actively being worked before additional grading is completed.
- 12. All exposed, disturbed areas must have erosion protection BMPs properly installed. This includes

all building pads, unfinished roads and slopes.

- 13. Perimeter protection and sediment control BMPs shall be maintained to provide protection from runoff during rain events.
- 14. Deployment of erosion control BMPs shall commence as soon as slopes are completed. Erosion control BMPs shall be installed and maintained for all completed slopes throughout the year.
- 15. Areas under active construction shall be adequately protected with erosion and sediment control BMPs prior to a rain event predicted at 50% or greater.
- 16. Inactive areas must be protected with erosion and sediment control BMPs as prescribed within the SWPPP. This includes building pads, unfinished roads and slopes. The ability to install BMPs in a prompt manner is not sufficient, BMPs must be installed for all inactive work areas.
- 17. When a Rain Event Action Plan (REAP) is required, it must be prepared in accordance with the CGP. A copy of each REAP must be placed in the project SWPPP and be available for review by the City inspector.
- 18. Treatment control BMPs shall be inspected weekly and prior to a forecasted rain event of 50% or greater. Treatment control BMPs shall also be inspected and/or serviced prior to October 1 of each year. Verification of these inspections shall be provided to the City upon request.
- 19. An updated SWPPP wall map is required to be maintained for all projects. The SWPPP wall map must reflect actual BMP installation / placement, dates, locations and status updates.

The RWQCB is responsible for verifying and enforcing requirements for projects subject to the CGP. The City will continue to work with RWQCB staff in assuring compliance at these sites. City staff will document observations of potential violations and will notify the RWQCB of noncompliance in accordance with the Municipal Permit. Project proponents are required to prevent construction-related materials, trash, wastes, spills or residues from entering a storm water conveyance system.

The City reserves the right to temporarily stop work on any construction site that may have the potential to discharge during a rain event due the improper installation of BMPs. Each site will be evaluated on a case by case basis to determine if a temporary stop work is necessary.

3.11 Additional Controls for Construction Sites within a Focus Area

Focus Areas are identified in the City's Jurisdictional Runoff Management Plan (JRMP) and Carlsbad Watershed Management Area Water Quality Improvement Plan (CWMA WQIP). Focus Area *16C-61 Drainage Area* is located north of Agua Hedionda Lagoon(refer to CWMA WQIP). For project sites located within a Focus Area, the following additional controls are required to be implemented at all times and to the maximum extent possible:

- 1. Maintain vegetative cover, as much as possible, by developing the project in a phased approach to reduce the amount of exposed soil at any one time.
- 2. Limit the areas of active construction to five acres at any one time.
- 3. Provide 100 percent soil cover for areas of inactive construction throughout the duration of the project.
- 4. Provide perimeter control at all appropriate locations and at all storm drain inlets. Perimeter protection shall be verified to be working order and improved as necessary to provide sufficient protection from run off during rain events.
- 5. Provide vegetated buffer strips between the active construction area and any water bodies.
- 6. Provide stabilized construction entrances that limit vehicle and foot traffic.

Where the provisions described above cannot be accommodated, additional or supplemental controls shall be recommended. The City Engineer or designee has the authority to approve supplemental or alternative control methods based upon an evaluation of the proposed control and the sites potential threat to storm water quality.

4. Storm Water BMP Inspection and Maintenance

4.1 General information

Construction is a dynamic operation where changes are expected. Storm water BMPs for construction sites are usually temporary measures that require frequent inspection and maintenance in order to remain effective. Relocation, revision, and re-installation, particularly as project grading progresses, may also be necessary.

4.2 Inspection of Construction Sites

The City inspects all construction projects. Inspectors are responsible for grading, infrastructure, CIP, right-of-way, storm water, and engineering projects to ensure construction activities are performed in accordance with the City Standards, permits, and all applicable codes, regulations and ordinances. In addition, project proponents are required to perform self-inspection of construction site activities, in accordance with these standards.

The City will evaluate the adequacy of the owner's/contractor's site management for storm water pollution prevention, inclusive of BMP implementation, on construction sites based on performance standards for storm water BMPs.

4.3 City Storm Water BMP Inspection Frequency

The inspection frequencies for determining compliance with the City and RWQCB requirements are based upon the potential Construction Threat Level as determined using Form E-32 available in the city website (refer to section 2.2). The inspection frequencies are shown in Table 8 below. Site-specific inspection frequencies are re-evaluated periodically, particularly when grading activities are being conducted during the rainy season. The need for additional inspections may vary depending upon several factors including:

- Site conditions:
- Previous violations:
- History of developer or contractor past performance;
- Grading during rainy season; and,
- Weather patterns.

Table 8: Inspection Frequency Based on Threat Prioritization

		Minimum Inspections Required													
Threat Priority	Jul	Aug	Sep	Oct	Nov	Dec	Jan	Feb	Mar	Apr	May	Jun	Minimum Wet Season Inspections	Minimum Dry Season Inspections	Minimum Required Inspections
High**	2	2	2	4	4	4	4	4	4	4	2	2	28	10	38
High	1	1	1	2	2	2	2	2	2	2	1	1	14	5	19
Medium**	1	1	1	2	1	2	1	2	1	2	1	1	11	5	16
Medium	1	0	1	1	1	1	1	1	1	1	0	1	6	3	9
Low	0	0	1	0	0	1	0	0	1	0	0	1	2	2	4

^{**}Inspection frequency for projects located within a WQIP Focus Area. Based on the City's identification of WQIP Focus Areas, the inspection frequency are different in these areas.

If sites do not comply with the City's requirements, inspectors will direct compliance and conduct followup inspections to assure compliance. Enforcement procedures are used when necessary and may include verbal or written warnings, stop work orders, revocation of permits and/or legal action.

4.4 City Storm Water BMP Inspection Requirements

Storm water compliance inspections for construction sites include, but are not limited to the following:

- 1. Assessment of BMP effectiveness including implementation of an effective combination of erosion, sediment and non-storm water BMPs to meet the City's minimum water quality protection requirements and prevent the discharge of pollutants into storm water and receiving waters;
- 2. Checking for coverage under the CGP if applicable;
- 3. Assurance of compliance with the City's applicable ordinances, permits and other site- specific requirements;
- 4. Visual observations for non-storm water discharges, potential illicit connections and potential discharge of sediment and other construction related pollutants in storm water runoff;
- 5. Documentation of violations and escalation of appropriate enforcement actions, when required;
- 6. Assurance of proper implementation of SWPPP (plans and specifications); and
- 7. Education and outreach on storm water pollution prevention as needed.

4.5 BMP Verification of Installation Required Prior to Occupancy

The City of Carlsbad BMP Design Manual, found in Volume 5 of the City of Carlsbad Engineering Standards, includes storm water guidelines for all development projects. Priority Development Projects require city-approved Storm Water Quality Management Plans (SWQMP), drainage studies, and construction plans that include hydromodification, low impact development, and treatment control best management practices (BMPs).

Pursuant to the Municipal Permit, the City must require and confirm that prior to occupancy and/or intended use of any portion of the project, that structural BMPs including LID, source control, and

treatment controls are inspected by the City and verified by the Engineer of Work (EOW). The EOW must verify that the BMPs are constructed and operating in compliance with the applicable requirements. To avoid project and occupancy delays, EOW verifications must include:

- <u>Prior to occupancy</u>, all permanent BMPs must be constructed per the requirements of approved plans and functionality must be verified <u>in writing</u> by the EOW. The verification letter must be certified with the EOW's stamp;
- Inspection and photographs of the installation of permanent BMPs must be completed at each phase of construction. Photos of the structures are required prior to construction, during, and at final installation;
- Informational signage, when required, must be designed, approved, and installed prior to occupancy. Please review the approved plans and permits for specific requirements;
- The developer is responsible for ensuring the permanent BMPs are not removed or modified by the new homeowner of HOA until the project has been finalized, found to be in full conformance with the approved plans and specifications and administratively closed-out;
- Provide contact information for the person, HOA, or management company responsible for the long-term maintenance and verification of the installed BMP(s); and

These requirements apply to all priority development projects subject to Volume 5 Carlsbad BMP Design Manual standards including phased development projects.